Lab 4: Implementing DHCP on a Router

Name: Abbirami.S.K

REG no: RA2211003050017

Aim: Configure a router to provide DHCP services to a network.

Objectives:

- 1. Set up a DHCP server on a router.
- 2. Configure network devices to obtain IP addresses automatically.
- 3. Verify the DHCP configuration.

Steps:

1. Open Cisco Packet Tracer:

• Create a new project.

2. Add Devices:

- o Add a Router: Drag a router (e.g., 2911).
- Add PCs: Drag multiple PCs and connect them to the router via a switch.

3. Configure DHCP on the Router:

```
Access the router CLI and configure DHCP: bash
```

Copy code

```
Router> enable
Router# configure terminal
Router(config)# ip dhcp pool LAN_POOL
Router(config-dhcp)# network 192.168.1.0 255.255.255.0
Router(config-dhcp)# default-router 192.168.1.1
Router(config-dhcp)# exit
```

4. Configure PCs to Obtain IP Addresses Automatically:

 On each PC, go to the Desktop tab, open IP Configuration, and select "DHCP."

5. **Verify DHCP Configuration:**

 On each PC, use the Command Prompt to check the assigned IP address with the ipconfig command.